MECHANICAL DOCK LEVELERS

TIER 1 ONLY

BASIC INSPECTION & LUBRICATION

Lubricate hinge tubes, cross-traffic legs, and pull rod assembly (if applicable)

Inspect spring bank

Inspect lip-flip mechanism

Inspect bumpers and bumper mounts

TIER 2 PLUS 1

INSPECTION & LUBRICATION PLUS

Inspect hold down assembly

Inspect deck and support beams for cracks and distortion

Inspect rear hinges, pins, and welds

Inspect and lubricate hinge tubes for cracks and broken welds

Adjust and lubricate spring bank & lip-flip mechanism

Operate board through full working range (above and below dock)

Basic pit cleaning & remove large debris*

TIER 3 PLUS 1+2 -

COMPREHENSIVE TOTAL CARE

Inspect weather seals and advise for authorization to repair and/or replace

Inspect cross-traffic legs and release chain; adjust as necessary

Inspect dock seals and dock shelters

Adjust restricting chain

Minor welding as needed

Advise on condition and structural soundness

Cleaning of Hold down as needed

Comprehensive pit cleaning *



HYDRAULIC / ELECTRICAL DOCK LEVELERS

TIER 1 ONLY 1 -

Basic Inspection & Lubrication

Lubricate hinge tubes

Inspect hydraulic cylinder for leaking seals
Inspect hydraulic lines for leaks or deterioration
Inspect hydraulic cylinder mounts to deck and subframe
Inspect bumpers and bumper mounts
Inspect deck and support beams for cracks/distortion
Inspect hinge tubes for cracks and broken welds
Inspect overall installation of board in pit and

TIER 2 PLUS 1 —

Inspection & Lubrication Plus

advise on overall condition

Inspect deck and support beams for cracks and distortions
Inspect hinge tubs for cracks and broken welds
Inspect overall installation of board in pit and advise
on overall condition

Inspect rear hinges, pins, and welds

Basic pit cleaning

TIER 3 PLUS 1+2 —

Comprehensive Total Care

Top off fluid levels

Inspect all electrical lines for pinched, bare and/or broken wires

Operate board through several cycles for correct functioning
of 'auto recycle'

Minor welding as needed

Comprehensive cleaning of pit, clearing of debris from rear hinges and weather seal

Inspect dock seals and dock shelters

*REMOVAL OF DEBRIS FROM SITE IS CUSTOMER RESPONSIBILIT

TURN OVER FOR TRUCK RESTRAINTS

BEST EQUIPMENT & WELDING

40 YEARS OF EXCELLENCE

Certified expertise and dedication to our products and services.

FOR MORE INFORMATION ON SERVICE, REPAIR, & PLANNED MAINTENANCE,

VISIT US AT bewinc.com

CORPORATE OFFICES

PHONE: 317-271-8652 FAX: 317-271-5879 EMAIL: SERVICE@BEWINC.COM

1960 MIDWEST BLVD. INDIANAPOLIS, IN 46214

JEFFERSONVILLE LOCATION

PHONE: 812-920-4141
EMAIL: SERVICE@BEWINC.COM

539 CHAMPION RD, JEFFERSONVILLE, IN 47130



LOADING DOCK
SERVICE SOLUTIONS

A COMPLETE SERVICE SOLUTION

At Best Equipment and Welding, we know downtime in your business is costly and we take it seriously. Our dedicated service teams located in Indianapolis and Jeffersonville will respond promptly to your dock equipment service needs with industry expertise and capabilities. We know how to identify the problem quickly and will be ready to fix the issue so that your operation can be operational as soon as possible. We also offer planned maintenance services to help identify and predict potential problems before they become serious and better ensure that your dock equipment stays available, efficient, and safe.

With Best Equipment and Welding, you can have confidence that your equipment will keep operating at peak productivity, efficiency and safety for all concerned.





INCREASEEVERYONE'S SAFETY

IMPROVEEFFICIENCY & RELIABILTY

PROTECT
YOUR INVESTMENT

SERVICE & REPAIR

Best Equipment and Welding service *all* dock manufacturers when your equipment needs service or repair. We service dock equipment products, including dock plates, dock bumpers, dock levelers, guard rails, dock ramps, dock shelters, dock restraints, high speed doors and more. With our fleet of fully equipped vehicles, experienced team of *certified welders and factory-trained service technicians*, we are a 'full service shop on wheels', specializing in all types of welding, fabrication, repair, installation, and maintenance services to complete any job, big or small, on the spot. You can count on BEW's service team to keep your dock areas productive and safe, while performing the repair on time, with minimal disruption to your operation.

PREVENTATIVE MAINTENANCE

Your dock leveler works long hard hours. Best Equipment and Welding Planned Maintenance programs on your dock equipment can save you precious time and significant dollars by reducing costly breakdowns and loss of time, help prevent workplace accidents, while extending the operating life of the equipment. BEW will design a program that is just right for your operation, schedule, and budget on an annual, semi-annual, quarterly or even monthly basis. These programs are focused on inspecting, maintaining, and predicting your equipment's health to optimize performance and address potential issues before they escalate into major problems.



TRUCK RESTRAINTS

(MANUAL OR PNEUMATIC)

TIFR 1 ONLY

BASIC INSPECTION AND LUBRICATION

Inspect and test inside and outside signal lights
Inspect condition of and lubricate moving parts
Inspect limit switches that control signaling lights

TIER 2 ** PLU

INSPECTION AND LUBRICATION PLUS

Inspect condition of activation drive system
Inspect condition of drive chain and springs

Inspect condition of bearings

Clear debris around restraint

SEVERAL STYLE UNITS MAY REQUIRE SIGNIFICANT
DISASSEMBLY: MANUFACTURER - SPECIFIC

(NOVA TRUCK RESTRAINTS)

TIFR 1 ONLY

BASIC INSPECTION AND LUBRICATION Inspect and test inside and outside signal lights

Inspect condition of lubricant

Verify proper air pressure for pneumatic activation cylinder

errry proper air pressure for pneumatic activation cylinds Inspect limit switches that control signaling lights

TIER 2 PLUS 1

INSPECTION AND LUBRICATION PLUS

Inspect condition of activation cable
Inspect/Removal of ram dampener

Inspect condition of cable pulley bearings

Inspect and adjust trailer sensor wand

BEST EQUIPMENT

& WELDING

FOR MORE INFORMATION ON SERVICE, REPAIR, & PLANNED MAINTENANCE,

VISIT US AT **bewinc.com**

CORPORATE OFFICES

PHONE: 317-271-8652 Email: Service@Bewinc.com

1960 MIDWEST BLVD. INDIANAPOLIS, IN 46214

JEFFERSONVILLE LOCATION

PHONE: 812-920-4141 Email: Service@Bewinc.com

539 CHAMPION RD, JEFFERSONVILLE, IN 47130